

Printronix Technical Bulletin	Number 7-0009	Revision A
	Product Type P7000	Date 11/08
Subject : NIC Web Server Name	Originator Ken Kuhn	Page 1 of 3

Problem description

When a customer uses the Web server name, the name for each printer must have a unique printer name.

P7000 printers with version 6 boards having the on-board NIC option (as opposed to the PCI NIC option) have a problem where the Web server name may default to P_000062.

When multiple printers are on the same system, and the customer uses Web server names, this could be a problem.

How to get the Web server name


- Obtain the printer assigned IP address.
- Open Internet Explorer.
- Type the printer IP address in the address box as shown below.



- Press the GO button.

The following screen should be displayed:

Welcome to Integrated PrintNet Enterprise



Welcome to Integrated PrintNet Enterprise

- Configuration** Integrated PrintNet Enterprise configuration forms.
- Status** Integrated PrintNet Enterprise status forms
- Help** Help for all forms
- About** System information
- Printronix** The Printronix web site.

Printronix Technical Bulletin	Number 7-0009	Revision A
Subject: NIC Web Server Name		Page 2 of 3

- Select the “Configuration / Integrated PrintNet Enterprise configuration forms”.

The following screen should be displayed



- Type the User name : root (Lower Case). Press the OK button. (No password needed.)

The following screen will be displayed

System Information

NOTE: Changes in server name setting only take effect after you reset the Integrated PrintNet Enterprise from

Name:

Description:

Location:

Contact:

Printer Serial Number:

Syslog: (e.g., 204.191.175.114)

Email: (e.g., username@domain.com)

SMTP server: (e.g., 204.191.175.114 or smtp.domain.com)

DNS server: (e.g., 204.191.175.114)

Printronix Technical Bulletin	Number 7-0009	Revision A
Subject: NIC Web Server Name		Page 3 of 3

Methods for changing server name

- Click into the box for the Name in the above screen, and enter a unique name.
- Click into the box and enter "P_XXXXXX" where XXXXXX is the last three pairs of the Mac Address.
- Example (P_800105) where the Mac Address = 00-08-96-80-01-05
- Store E-Net to Default.

Store E-Net to default

Warning: When using E-Net to default the current IP, Gateway and Subnet Mask will return to the Printronix Default settings.

Below are the steps to be executed to store E-Net to Default. After this has been done, the printer will reset twice. After the printer comes back On-Line, use the methods above and verify the server name has been changed.

- | | |
|---|--------------------------------------|
| • Press On-Line button | (Offline / Quick Setup) |
| • Press the UP and Down arrows at the same time. | (Enter Switch / Unlocked) |
| • Press the UP, Down, Left and Right keys at the same time. | (Factory / Set coil Temp) |
| • Press Next key until display reads. | (Factory / Printer mgmt) |
| • Press down key. | (Printer mgmt / Debug Port
cfg) |
| • Press next key until display reads. | (Printer mgmt / E-Net to
default) |
| • Press Enter key. | (Printer will reset twice) |

For any questions, please call your local Printronix Customer Support Center.